

Colette
PATTERNS

3006
KNIT SLIP
FLORENCE




INSTRUCTIONS



YOU WILL NEED:


- *Florence Pattern*, from *Seamwork Magazine*
- 1 ¹/₄ yard clear elastic
- ³/₄ yard 60" wide knit fabric


SUBSECTION




1. Cut all fabric according to cutting layout on page 7 of the pattern instructions.

2. Measure full hip, then take this measurement and add 4". For example, if your hip measures 39", then $39" + 4" = 43"$. Cut a rectangle that is this measurement in width by 22" in length. This will be the skirt of your slip






3. Assemble the Florence bra according to pattern instructions, complete through page 12. The bra should be fully sewn save the bottom band elastic.



4. Measure the bottom edge of the bra band and subtract 2". Wrap the $\frac{1}{4}$ " clear elastic around your rib cage just under the bust, and adjust if necessary. Add $\frac{3}{4}$ " for seam allowance. Cut the elastic. On the wrong side of the skirt, Pin elastic so that it is evenly distributed. Once the elastic is flush with the raw edge of the waistline, baste it in place, stretching the elastic to fit as you sew. When you release the elastic, the skirt will be shirred.



5. Pin along the short edge of knit rectangle. Sew at $\frac{3}{8}$ " seam allowance using your preferred stretch stitch.



6. Sew Shirred edge to Florence with the right side of the skirt facing the wrong of the lace band. Pieces should overlap by $\frac{1}{2}$ ". Sew in place using a zigzag stitch.
7. Hem slip to complete.